



INSTANT MEDIC FLEX

STEP 1: PREP

1. Prep the area to be repaired
 - a. Remove any loose concrete material from the repair area
 - b. Clean the area with a Nyalox brush or wire wheel and vacuum so it is free of dust.
 - i. For cracks wider than 1/8" and saw-cuts it is best to clean them with a diamond blade.

STEP 2:

1. Mix Instant Medic Flex
 - a. Add color pack into "A" side; quart jug
 - b. Add "B" component to "A"; quart jug
 - c. Mix with an arrow mixer and drill for at least 2 minutes. Raise and lower the drill while mixing. Insure all sides of the container have been touched with the arrow mixer and color is uniform throughout the material.



STEP 3:

1. Pour mixed product into repair cavity
 - a. Cut tip of product container to desired size to dispense
 - b. Dispense product into the crack or saw cut slightly overfilling
 - i. Refill "sinkers" before the product cures out



STEP 4:

1. Clean excess product
 - a. Allow product to dry tack free usually 1-Hour depending on temperature and humidity
 - b. Clean overfilled product with a razor scraper

Note: Instant Medic Flex does not like moisture. Insure that the cavity the product is being applied to is bone dry. Also, product is ready for traffic as soon as it can be shaved; as little as one hour. It does take approximately 24-Hours to reach full hardness. Do all repairs before any polish, staining or coating work is to begin.

