

# U PREP IT™

## INTERIOR PREP SYSTEM

### STEP 1: PREP

1. Completely wet the floor with water
2. Liberally spray Super Blue on the floor with a pump sprayer
3. Run the Concrete DNA™ Diamond Satellite Pad (30 Grit) on the floor using a low-speed buffer, propane burnisher or auto scrubber
4. Squeegee and wet vac the dirty water from the floor before it dries
  - a. Your floor should have a “chalkboard” appearance and have a slight scratch in it that will help your sealer or coating to bond



### STEP 2:

1. Run the red pad with plenty of water mixed with the diluted Ez-Clean to clean and lift any remaining dirt from the floor.
2. Squeegee and Vac the dirty water from the floor before it dries.
  - a. Let your floor dry the necessary amount of time before applying your sealer or coating.

