

Prospective Job Timeline

Clear Coat

- 8am-11am
 - Grind
- 11am-12pm
 - Clear Prime
 - Let dry completely (tack free)
- 4pm or after
 - Put down WB Urethane (gloss or matte)

DONE