

U-Polish-It

Level 2 Concrete Polishing System

1. Step 1

- a. Run Concrete DNA™ satellite pads starting with the 50 grit pad. Utilize these pads on a low speed floor buffer, auto scrubber, or propane burnisher.

Note: Pads should be ran wet and at a low speed

- b. Double pass each grit.
- c. Run grits 50, 100, 200, 400 (do not skip grits). Squeegee dirty water off of the floor between grits before it has time to dry.

2. Step 2

- a. Clean the floor thoroughly. Note: Do not leave dust marks or footprints
- b. Densify floor with Concrete DNA™ Densifier. Apply at a rate that the floor stays wet with densifier for 15 minutes or more. (Typically 300 sq ft per gallon)
 - i. Let densifier dry until floor is dry on the surface.

Note: It is best to let densifier dry overnight to further harden the floor

3. Step 3

- a. Continue polishing the floor with the Concrete DNA™ Satellite pads in the 800, and 1500 grit (run these pads wet)
- b. Thoroughly clean the floor

4. Step 4

- a. Apply Concrete DNA™ Polishing Guard Gloss (dilute 1:1 with water) by spraying it on the floor and spreading it with a microfiber. Apply at least two thin coats. This product goes down thin to win.
 - i. We also have a Polishing Guard in a Matte finish. It is not to be diluted.
- b. After it is dry and cannot be marked by touching buff with Concrete DNA™ Double sided 3000 pad. You can buff with a low speed buffer, but a high speed buffer will produce more shine. Buffing is highly recommended for our Gloss version.