



## EPOXY COLOR SYSTEM

### STEP 1: PREP

1. Run Concrete DNA™ Satellite 30-Grit Pad under a low-speed floor buffer in conjunction with Super Blue. You want the floor to have a chalkboard look to it.

**WHEN USING WATER TO PREP A FLOOR ALLOW A MINIMUM DRY TIME OF 12-24 HOURS BEFORE APPLYING THE BASECOAT.**



### STEP 2:

1. After the floor has sufficiently dried apply a coat of Epoxy M.V.B.
  - a. Mix desired Epoxy Color Pigment into the M.V.B.
  - b. Squeegee onto the floor using a 1/8<sup>th</sup> notched squeegee
    - i. Walk through product with spiked shoes
  - c. Use a 3/8<sup>th</sup> Nap roller to back-roll the product.



### STEP 3:

1. Apply a coat of Poly 80 Slow
  - a. Mixed Desired Aspartic Color Pigment into the Poly 80 Slow
  - b. Squeegee onto the floor using a 1/8<sup>th</sup> Notched squeegee
    - i. Walk through the product with spiked shoes
  - c. Use a 3/8<sup>th</sup> Nap Roller to back-roll the product
    - i. Monkey Grip can be added to this coat for additional traction

