



ENVIROSTAIN "WATER BASED" STAIN SYSTEM

STEP 1: PREP

1. Prepare the floor with our Concrete DNA Satellite Pads; 30 Grit
 - a. Run the pad with plenty of water under a low speed floor machine
 - b. Add a dilution of 1-Part Super Blue to 9-Parts water to floor to help open the concrete.
 - c. Squeegee water and remove from the floor with a wet/dry vac
 - d. Insure the floor is clean of dust and footprints by lightly mopping
 - e. Let the floor dry



STEP 2:

1. Stain the floor with Concrete Floor Envirostain "water based stain"
 - a. Spray the floor with the stain and insure 100% coverage, generally 300 square feet per gallon
 - b. Microfiber the stain into the floor insuring not to leave streaks.
 - i. A small mock up area is always recommended before doing the entire floor
2. Let the stain dry on the floor; preferably overnight.



STEP 3:

1. Seal the floor with Concrete Floor Supply Ez-Seal
2. Ez-Seal can be applied with a microfiber flat mop or 3/8th Nap Roller Cover
3. Apply at least 2 thin coats



STEP 4:

1. Apply Ez-Glo floor finish for sacrificial protection
 - a. Allow sealer to dry for at least 12-hours
 - b. Apply at least one coat of Ez-Glo. Spray and microfiber the floor.
 - c. Buff with a 3000-Grit Concrete DNA Double Sided Diamond Pad if desired.

